



# FantiniCosmi

FANTINI COSMI S.p.A.

Via dell'Osio, 6 20090 Caleprio di Settala, Milano - ITALY  
Tel. +39 02 956821 | Fax +39 02 95307006 | [info@fanticosmi.it](mailto:info@fanticosmi.it)  
EXPORT DEPARTMENT  
Ph +39 02 95682229 | [export@fanticosmi.it](mailto:export@fanticosmi.it)  
[www.fanticosmi.com](http://www.fanticosmi.com)



## EV87 EXPANDABLE MULTIFUNCTION CLIMATIC CONTROL UNIT

### ***Employment***

The EV87 climatic controller is suitable for the thermoregulation with remote management of all types of heating systems and floor-type air-conditioning systems. For the thermoregulation of particularly complex systems, the EV87 controller acts as central controller (MASTER) and can be connected to other EV-series controllers (called SLAVE) via a communication bus called FANBUS.

### ***Description***

The EV87 controller can be set as climatic controller for heating system through mixer valve, or for air-conditioning system still through mixer valve or it can be set as fixed point / sliding point / controller for boilers.

### **Mixer valve**

- 3-way mixer valve control open/close/stop
- Circulation pump control with delayed switch-off
- Auxiliary relay control for a domestic water storage tank or for a 1-stage boiler
- Delivery temperature regulation according to the min./max. limit (to be set)
- Delivery temperature regulation according to the ambient temperature read (to be set)

### **Boilers**

Boiler management modes are the following:

- Management of one boiler with 2 or 4-stage burner
- Management of two boilers in cascade
- Management of three boilers in cascade
- Management of four boilers in cascade
- Management of two boilers in cascade with 2-stage burner

The boiler management provides to set the days of rotation of the main boiler.

### **Climatic regulation**

The controller calculates the delivery temperature value at all times as a function of the ambient temperature set, the external temperature read and the broken regulation curve set. The calculated delivery temperature can be further regulated through the limit probe and the ambient probe described in the following pages.

### **Fixed point regulation**


It is used to control the boiler. It regulates the delivery temperature according to a fixed temperature value to be set.

### **Sliding point regulation**

It is used to control the boiler. The EV87 controller, via FANBUS, acquires the delivery temperature required by each connected SLAVE module. The max. temperature value required is added to the temperature value set thereby obtaining a variable boiler temperature control according to the system requirements.

The EV87 controller features two digital inputs to be used as alarms. Furthermore a serial line can be connected to a modem, thus enabling the control unit to transmit any system fault to a remote station (e.g.: mobile phone or PC), and to be remotely managed using SMS messages or DATA transmission.

## Front panel with configuration keys and indications




## Broken regulation curves

The EV87 controller has a winter curve and a summer curve to be used to calculate the delivery temperature. The curve is selected through the heating period and the cooling period set. Both curves represent the delivery temperature as a function of the external temperature to obtain 20 °C ambient temperature, and are used for climatic regulation.

To obtain different ambient temperature values, the broken regulation curve moves along the line  $+Ta..Ta$ . The relation that establishes the delivery temperature value as a function of the external temperature depends on the thermal properties of the building and, for optimum comfort, must be found by experimenting.

## Winter broken regulation curve



N.B. In systems with panels, limit the delivery temperature values to max. 45°C.

### **Preset values for the WINTER broken regulation curve**

	External t1	External t2	External t3	External t4
T ext (°C)	20	10	0	-10
	TM1	TM2	TM3	TM4
T M. (°C)	20	40	60	80

### **Preset values**

In the winter broken regulation curve you can set for the four points, both the external temperature values and the delivery temperature values in order to adapt the EV87 controller to whatever condition.

**N.B.** Modify the external temperature values only in the event of special external temperature conditions.


External temperature values (External t1..... External t4) can be set from -30°C min to 30°C max. External temperature value is always included between its two limit values set.

$30^{\circ}\text{C} \geq \text{External t1} > \text{External t2} > \text{External t3} > \text{External t4} \geq -30^{\circ}\text{C}$

Delivery temperature values (TM1.....TM4) can be set from 5°C min to 99°C max. External temperature value is always included between its two limit values set.

$5^{\circ}\text{C} \leq \text{TM1} < \text{TM2} < \text{TM3} < \text{TM4} \leq 99^{\circ}\text{C}$

### **Summer broken regulation curve**



The two limit values of the broken regulation curve (TextMin - TextMax), can be customized for system optimizations, if required.

### **Preset values for SUMMER broken regulation curve**

	r1	r2	r1	r2	r1	r2	r1	r2
External t. limits	40	35	30		27		25	20
Preset external t		35		30		27		23
Delivery t limits	15	25	15	25	15	25	15	25
Preset delivery t		17		18		19		20


Summer curve **Text\_Max** can range between **35°C min** and **40°C max**.

Summer curve **Text\_Min** can range between **20°C min** and **25°C max**.

The delivery temperature relevant to an external temperature is always included between the two limit values set for the delivery temperature.

### **Switch-on time optimization (winter only)**

Like for the delivery temperature, the advance switch-on time is calculated automatically by interpolation, using the advance switch-on time values set for four external temperature values. Advance switch-on times are set in the same menu used for setting the four delivery temperature values.




The max value that can be set is 10.00 hours. Optimization is excluded by setting advance times to zero (00.00 h). Also in this case, the value relevant to an advance time is always included between its set limit values:

$$0h \leq H1 < H2 < H3 < H4 \leq 10h$$

The controller calculates, as a function of the external temperature, how much earlier the system is to be activated with respect to the first ON time of the present day. During the whole advance switch-on time, the delivery temperature value regulated is the value set in the "Configuration" menu as delivery temperature value in forced operating mode.

## Temperature probes

The temperature probes are the detecting devices through which the control unit receives the temperature values fundamental for its operation. The sensitive element is composed of NTC thermistors.



**EC10:** Ambient probe /Correction

**EC14:** External probe

**EC15:** Delivery probe / limit probe / auxiliary contact probe

**EC16:** Delivery probe / limit probe / auxiliary immersion probe

## Technical data

- Thermoplastic waterproof enclosure protected to IP55 (\*)
- Cable gland G  $\frac{1}{4}$  (\*)
- Operating temperature from -40°C to +80°C (\*)
- Connection between probes and control unit via two-wire cable with minimum section 1 mm<sup>2</sup> and maximum length 1000 metres
- Do not place the probe connections in close proximity to distribution cables to avoid induced disturbances.

(\*) For ambient probe EC10, refer to the corresponding instruction sheet

**N.B.** The control unit also works with probes: EC81 (external probe) EC82 (contact probe) and EC83 (immersion probe).

### Installing the external probe EC14

Install the external probe on the north or north-west wall of the building, or in any case at least 2.5 metres from the ground and in a vertical position. Fit the probe far from sources of heat and protruding parts. If it cannot be fitted on the north side, fit it on the wall considered the coldest and, where possible, in a position protected from sun rays.

## ***Installing the delivery-limit-auxiliary probe EC15-EC16***

The contact probe EC15 must be fixed to the water pipe with the specific strap, with heat conducting paste interposed to guarantee correct heat conduction.

The immersion probe EC16 must be fitted in an elbow provided in the piping.

## ***Installing the ambient probe EC10***

Install the ambient probe on an interior wall at a height of 1.5 m, away from heat sources, windows and doors. The probe wiring depends on the mode of use:

- Ambient probe
- Changing of the set-point of the Day Temperature (remote control mode).

For wiring, refer to the corresponding EC10 probe instruction sheet.

**N.B.** The ambient probe EC10 is connected to the inputs used for the auxiliary probe, the use of one probe therefore excludes the other.

## ***Operation periods***

The EV87 controller regulates the delivery temperature using the winter broken regulation curve or the summer one, according to the heating or air-conditioning period set. If the current period is not included in these two set periods, the controller will set in STAND-BY and will close the valve and shut down the pump. If due to a setting fault, the two periods overlap, the heating period will prevail.

### ***Heating period***

By setting the heating start and stop date you establish the operating period of heating. Out of this period no set programme is considered and a STAND-BY operating mode is actuated.

### ***Air-conditioning period***

By setting the air-conditioning start and stop date you establish the operating period of air-conditioning. Out of this period no set programme is considered. The air-conditioning period can be excluded by setting the dashes (---).

## **Operation programmes**

The EV87 controller works with different programmes selectable by the user.

- **Valve Opens (\*)**

The circulation pump is started and the mixer valve is opened manually.

- **Valve Closes (\*)**

The circulation pump is shut down and the mixer valve is closed manually

- **Antifreeze**

The ANTIFREEZE temperature set for calculating the delivery temperature is used only when within the heating/air-conditioning period.

- **Night**

The NIGHT temperature set for calculating the delivery temperature is used only when within the heating/air-conditioning period.

- **Day**

The DAY temperature set for calculating the delivery temperature is used only when within the heating/air-conditioning period.

- **Auto Weekly 1/ Weekly 2/ Daily**

The ambient temperature to be used for calculating the delivery temperature is selected according to the chosen programme (**Weekly 1 / Weekly 2 / Daily**) and the performed programming.

The automatic programme provides the selection between two weekly programmes and one daily pro-

gramme. Both weekly programmes provide for each day of the week 3 on and off time bands whereas the daily programme provides 3 on and off time bands to be used for the whole week.

(\*) Programme that can be selected only if the controller is configured as **VALVE**.

During controller operation the user is informed on the current selected operating mode through display, SMS messages or modem data communication. Operating modes are the following:

a. **Day operating mode**: when climatic regulation is performed by regulating the Day ambient temperature.

b. **Night operating mode**: when climatic regulation is performed by regulating the Night ambient temperature.

c. **Reduced operating mode**: when climatic regulation is performed by regulating the Reduced ambient temperature.

d. **Antifreeze operating mode**: when climatic regulation is performed by regulating the Antifreeze ambient temperature.

e. **Off operating mode**: when regulation is performed on an ambient temperature excluded (dashes are set)

f. **Stand-by operating mode**: when the Automatic programme has been selected and the heating/air-conditioning period is ended.

- g. **Forced operating mode**: when performing optimization (advance switch-on time) used in automatic programme.
- h. **Operating mode -----**: when regulating boilers (fixed point/sliding point).
- i. **Temporary operating mode**: when the temporary heating period is set.

### ***Limit probe***

The limit probe can be used to limit the value of the delivery temperature. When the temperature measured by the probe drops below a certain value (**minimum limit used as anti-condensation**) or rises above a set value (**maximum limit used, for example, in panel systems**) the controller reduces the delivery temperature value proportionally.

**N.B.** The function is excluded when the set point is excluded by dashes (----). If a set point is set by mistake and the probe is not connected, an alarm is triggered.

### ***Auxiliary regulation***

The auxiliary probe can be used in three different ways:

1. Auxiliary probe
2. Ambient probe
3. Set correction

### ***Auxiliary probe***

The measurement probe (**EC15 EC16**) can be used, associated with the control relay 4 - described in the next pages - as a part of an auxiliary controller.

According to its configuration the following operation options can be selected:

1. **FIXED** point temperature, to control a boiler or the pump of a domestic water storage tank at a constant temperature,
2. **SLIDING** point temperature, in this case the set point value represents the amount of degrees the boiler (connected to the auxiliary relay) must be regulated above the temperature value required by the EV87 controller and the SLAVEs (EV19A EV19B).

### ***Ambient probe***

The measurement probe (**EC10**) is used to measure the ambient temperature.

The measured value is compared with the desired ambient temperature value (Day t - Night t - Reduced t - Antifreeze t) and on the basis of the difference read the delivery temperature required by the climatic controller is corrected proportionally. The correction factor for the delivery temperature is selected by setting the parameter **K**, called ambient temperature authority

$$\text{TMC} = \text{TMC (broken regulation curve)} +$$

### **(2K \* (Ambient t set - Ambient t))**

where TMC is the delivery temperature calculated and Ambient t set is the desired ambient temperature.  
Example:

Ambient t set = 20°C    Ambient t read = 18°C

K = 1.0

TMC = 40°C

$$\text{TMC} = 40^\circ\text{C} \text{ (TMC broken regulation curve)} + (2 \cdot 1.0 \cdot (20 - 18)) = 44^\circ\text{C}$$

### **Set correction**

The measurement probe (EC10) is used as remote control for correcting the "DAY" temperature set point

**N.B. For ambient probe/set correction wiring refer to the corresponding EC10 probe instruction sheet.**

### **Probe 4..20mA**


Input 4..20mA can be used to control whatever physical unit (e.g. temperature, humidity, pressure, etc...). Associating it to the control relay 4 - described in the next pages - will obtain a set min or max ON-OFF control.

Input is customized by entering the values corresponding to 4mA and 20mA, the associated unit of measurement and the operation set point. The function is automatically excluded if the probe is not connected.


### **Output 0..10V**

The controller is fitted with 0..10V proportional output, used to control a servo valve for example, in order to keep the calculated delivery temperature constant.

By setting the proportional range (**2.0°C min - 20°C max**), the proportional output shall be 0V when the delivery temperature coincides with the calculated temperature value and it shall be 10V when the delivery temperature is equal to the calculated temperature value less the proportional range.



## **Relay**



**Relay 1** terminal board 2 contacts 1 - 2

**Relay 2** terminal board 2 contacts 4 - 5

**Relay 3** terminal board 2 contacts 6 - 7

**Relay 4** terminal board 2 contacts 8 - 9

## **Mixer valve operation**

- Relay no. 1 = Valve opens
- Relay no. 2 = Valve closes
- Relay no. 3 = Pump control

## **Burner/boiler operation**

- Relay no. 1 = "Burner stage 1" or "Boiler 1" or "Boiler 1 Stage 1"
- Relay no. 2 = "Burner stage 2" or "Boiler 2" or "Boiler 1 Stage 2"
- Relay no. 3 = "Burner stage 3" or "Boiler 3" or "Boiler 2 Stage 1"
- Relay no. 4 = "Burner stage 4" or "Boiler 4" or "Boiler 2 Stage 2"

When setting the operating mode: 4-Stage Burner or 4 Boilers or two 2-stage burners, **relay no. 4** cannot be used for other functions.

In all the other cases, **relay no. 4** can work in different operating modes according to its setting in the "Configuration" menu. e.g.:

- 1. AUTOMATIC:** the relay is closed during the operating modes: Day Reduced and Forced, is open in all the other cases
- 2. PROBE 4..20mA:** the relay is closed when the value measured is below (max limit) or above (min limit) the preset set point
- 3. AUX. PROBE:** the relay is closed when the measured temperature is lower than the preset set point
- 4. DIGIT INPUT 1:** the relay is closed when the digit input 1 closes
- 5. DIGIT INPUT 2:** the relay is closed when the digit input 2 closes

**6. DIGIT INPUT 1 2:** the relay is closed when the digit input 1 or 2 closes

### **Circulation pump control**

The circulation pump is controlled automatically. The pump is automatically shut down when in the winter period the delivery temperature calculated drops below the preset TM min limit value or when in the summer it rises above the preset TM max limit value. The limit values TM min and TM max are set in the "Configuration" menu. To exploit residual heat accumulated during the day to a maximum, the pump shuts down after a certain delay which can be set in the "Configuration" menu.

### **Domestic water priority**


When the auxiliary regulation is set as auxiliary probe (**see para. Auxiliary regulation**), in the "Configuration" menu the domestic water priority function can be enabled. When the temperature measured by the auxiliary probe drops below the set value, the mixer valve is closed. Regular operation will restart as soon as the temperature rises above the set value.

**N.B.** Priority function is active even if relay no. 4 is not associated to auxiliary regulation.

### **FANBUS**

Via the communication bus called "FANBUS", the EV87 controller which acts as MASTER control unit can be connected to up to **20 SLAVE expansion modules** of the EV\_ series.

The FANBUS connection between MASTER and SLAVE is performed with a simple low voltage non-polarized twin cable.



### **Control unit address**

Each control unit is identified by two digits that determine its address. The first digit represents the model and cannot be modified. The second one may be set through jumpers on each SLAVE terminal board. Example:

EV91A      first digit: 1

EV91C      first digit: 2

EV92      first digit: 3

Should several control units of the same type (max. 8) be connected to the bus, set an address for each

control unit in order that every control unit will have an address that identifies it unambiguously.

**N.B. The MASTER control unit EV87, like SLAVE modules, has a fixed address: "00".**

#### List of connectable SLAVE modules

- EV91A Climatic regulation module
- EV91B Module for domestic water temperature regulation
- EV91C Module for regulating two 1-stage boilers in cascade
- EV91D 4 generic outputs module
- EV92 8 digital inputs module


#### Searching SLAVE modules on the BUS

Each time a new or several slave modules are connected to the BUS, you have to run the recognition procedure in the menu "Search SLAVE". This procedure enables to memorise the addresses of the new modules connected, that will be periodically queried and provided with the information necessary for their regular operation (Time - External temperature - etc...)

## SYSTEM EXAMPLES


### Heating of 1 area with one 1-stage boiler

1 Comando Caldaia relay Ausiliario




- 1 Auxiliary relay boiler control
- 2 Auxiliary boiler probe
- 3 Optional limit probe
- 4 Relay 1 and 2 valve control
- 5 Pump control
- 6 Delivery probe
- 7 External probe

#### **Heating of 1 area with domestic water storage tank**




- 1 Auxiliary domestic water pump control
  - 2 Domestic water temperature probe
  - 3 Optional limit probe
  - 4 Relay 1 and 2 valve control
  - 5 Pump control
  - 6 Delivery probe
  - 7 External probe


### **Heating of 2 areas with one 1-stage boiler and 1 domestic water storage tank**




### **Heating of 3 areas with one 1-stage boiler (1 EV87 + 2EV91A)**




**Heating of 2 areas with two 2-stage boilers in cascade (1 EV87 2 EV91A)**



**Heating of 2 areas with four 1-stage boilers in cascade (1 EV87 2 EV91A)**




**Heating/Air-conditioning for panel systems**




## Wiring diagrams


### Terminal board wiring diagram




### Wiring diagram for control of mixer valves with servo control supplied at 230VAC




**Wiring diagram for control of mixer valves with servo control supplied with voltages other than 230VAC**




**Wiring diagram for ON-OFF control of four 1-stage boilers**



**Wiring diagram for ON-OFF control of two 2-stage boilers**




**Wiring diagram for ON-OFF control of a 4-stage burner boiler**



## **Operation with 2/4-stage boilers or boilers in cascade**

The controller compares the delivery temperature value calculated, with the value measured by the temperature probe and if this differential value drops below the set one, the first stage or the first boiler are switched on. In case the differential value between the two temperatures (calculated and measured) is equal to or more than the double set differential, also the second stage or the second boiler will be switched on and so forth for stages/boilers 3 and 4.

In the operation with boilers in cascade, to obtain even boiler consumption you can set **an automatic rotation time for the main boiler** that can be regulated from 0 to 20 days max.




Control sequence for 2/4-stage boiler or 2/4 boilers in cascade or two 2-stage boilers

## **Alarms and Failures**

**The EV87 controller manages the following alarms:**

- 1. Digital inputs alarms:** two voltage free digital inputs that can be used for example to detect gas leaks and boiler cut-off. The status of both digital inputs is displayed in the “**Remote Management**” menu. Connect contacts as shown in the figure on next page:



**2. External probe and delivery probe alarms:** these alarms are triggered when these probes are disconnected or short circuited. Should the external probe be faulty, the controller will use the last external temperature value measured. In the event of failure to the delivery probe in valve operation, the valve is stopped and the pump is kept in the current conditions whereas in the burner/boiler operation everything will be shut down.

**3. Limit probe and auxiliary probe alarms:** these alarms are triggered when these probes are disconnected or short circuited. These alarms however are only active if the set-point has been set in the “*Limit probe*” menu or in the “*Auxiliary Regulation*” menu.

**4. Limit threshold exceeded and 4..20mA threshold exceeded:** through the “*Remote Management*”

menu you can enable the function Send message for limit threshold and 4..20mA threshold exceeded (see paragraph “*Remote Management*”)

**5. Delivery temperature not reached in mixer valve operation:** through the “*Remote Management*” menu you can enable the function Send message for delivery temperature not reached after a period of time ranging between 2 and 9 hours (see paragraph “*Remote Management*”). This alarm can be used to signal a malfunctioning of the mixer valve. This function will be automatically deactivated at the end of the alarm cycle.

## ***Settings and Adjustments***

### ***Factory settings***

The EV87 control unit leaves the factory with all parameters set for standard operation. These parameters can be customized according to the system type. **Should it be necessary to reset factory parameters** (default data), proceed as follows: turn off the power supply, then turn it on again while pressing the “+” key. All data entered will be lost, while factory parameters will be reset as well as the password.

### ***Adjustments***

Use keys “▲” and “▼” to scroll the main menu and to move the cursor over a submenu.

Use keys “◀” and “▶” to open the selected menu and to scroll the submenu pages

Use keys “+” and “-” to change the parameters highlighted by the blinking cursor

### **Password**

The control unit is provided with a password to prevent unauthorized parameters modifications. Time setting and parameters displaying in the “Information” menu are enabled although the password is not entered.

The password consists of four alphanumeric characters and its default value is:

**“1000”**

The password can be changed.

**N.B.** The password is not automatically deactivated, it is therefore essential to deactivate it manually at the end of the setting procedures, to disable all menus.

## **CONTROL UNIT CONFIGURATION MENU**

### **Main menu**


The menu without the password is the following:

- MENU -->
- .....
- >Information
- >Set Current Time
- >Enter PASSWORD
- .....

The menu with the password is the following:

- MENU -->
- .....
- >Information
- >Set Current Time
- >PASSWORD Set
- >LANGUAGE Set
- >Heating time
- >Cooling time
- >Program
- >Temp. setting
- >Time setting
- >Winter curve
- >Summer curve
- >Configuration
- >Limit Sensor
- >4..20mA Sensor
- >Aux Regulation
- >Remote Manage
- >Recording
- >SLAVE Menu
- .....

## Information



**Submenu 1:** Displays the current time and date, the external temperature and the delivery temperature measured at that moment

**Submenu 2:** Displays the limit temperature, the auxiliary temperature and the value translated by the probe 4..20mA at that moment

**Submenu 3:** Displays the operating period (SUMMER/WINTER/----) according to the heating/air-conditioning periods set, the set programme and the current operating mode

**Submenu 4:** Displays the ambient temperature to be obtained, the delivery temperature calculated by the controller and the max. delivery temperature required by the SLAVES (Remote T.)

**Submenu 5:** Displays the first ON time, the calculated advance switch-on time and the real switch-on time

## **Set Current Time**

.....  
>Information  
>Curr. Time Set  
>PASSWORD Set

Set timing  
day: Monday  
Hour: 10:16  
Date: 14/APR./2006

### **Submenu 1**

Day light time  
actual: LEGALE  
start: 26/MAR  
End: 29/OTT

### **Submenu 2**

**Submenu 1:** Move the cursor and press the keys “+” and “-” to set: Day, Time, Date, Month and Year

**Submenu 2:** Move the cursor and press the keys “+” and “-” to set the daylight saving start and stop Day and Month. The controller will calculate automatically when changing the time.

## **Enter Password**

>Information  
>Curr. Time Set  
>PASSWORD Set  
>LANGUAGE Sel.

Set  
Password code  
Password: 1000

### **Submenu 1**

Modify  
Password code  
Password: 20A0  
Confirm: 20A0

### **Submenu 2**

**Submenu 1:** Move cursors to the password digits to set and use keys “+” and “-”. Submenu 2 will be only enabled if the password entered is correct

**Submenu 2:** Enter the new code in the Password line and repeat it for confirmation in the next line to change the password code enabling the set-up menus

To enter the new password, the 4 characters must be entered both in the “Password” and in the “Confirmation” fields. To confirm it is essential that the cursor is blinking on the last “Confirmation” character and to press the key “>” (forward).

When in this position, pressing the forward key will automatically confirm the new PASSWORD and go back to submenu 1 "Enter password code"

Password:	1	A	2	1
Confirmation:	1	A	2	1

### **Heating period**

>PASSWORD Set  
>LANGUAGE Sel.  
>Heating Time  
>Cooling Time

Heating period  
On: 01/GEN  
Off: 31/DIC

**Submenu 1**

Temporary progr.  
Ambient T.: 20.0c  
days no.: 01  
Hrs no.: 23

**Submenu 2**

### **Choose LANGUAGE**

>Curr. Time Set  
>PASSWORD Set  
>LANGUAGE Sel.  
>Heating Time

Language Selection  
ENGLISH

**Submenu 1**

**Submenu 1:** Use keys "+" and "-" to select the required language: Italiano - English - Français

**Submenu 1:** It is used to set the heating period start and stop day and month for all programmes.

**Submenu 2:** It is used to set a temporary programme to keep a certain ambient temperature for a maximum period of 99 days and 23 hours.

N.B. The temporary programme prevails on the automatic programme selected, for the whole set period of time

## **Cooling period**

>LANGUAGE Sel.  
>Heating Time  
>Cooling Time  
>Program

Cooling  
period  
Start: --/-  
Stop: --/-

### **Submenu 1**

Cooling Flow  
Temp. Limits  
Max: 25.0c  
Min: 15.0c

### **Submenu 2**

## **Programme**

>Heating Time  
>Cooling Time  
>Program  
>Temp. Setting

Operating programme:  
AUTO WEEK. 1

### **Submenu 1**

**Submenu 1:** Use keys "+" and "-" to select the required programme

**N.B.** If in the "Configuration" menu the controller has been configured for boiler control, the programme VALVE OPENS and CLOSES cannot be selected.

**Submenu 1:** It is used to set the air-conditioning start and stop day and month. Dashes exclude air-conditioning

**Submenu 2:** It is used to set the calculated min and max delivery temperature, from a minimum of 10°C to a maximum of 35°C

## **Set Temperature**

>Cooling Time  
>Program  
>Temp. Setting  
>Time Setting

Comfort T: 20.0c  
EconomyT: 17.0c  
Night T: 15.0c  
AntiFr T.: 05.0c

### **Submenu 1**

- Set time: **ON1: 07.00 - OFF1: 12.00**

**ON2: --- - OFF2: ---**

**ON3: 17.00 - OFF3: 22.00**

Between 07.00 and 12.00 Day T. is used; between 12.00 and 17.00 Reduced T. is used; between 17.00 and 22.00

Day T. is used and after 22.00 Night T. is used up to the first ON of the next day.

Antifreeze temperature is used when the Antifreeze programme is selected.

**Submenu 1:** Set the required ambient temperatures. If heating is to be excluded, for example at night, set a value below zero; “---.“ will automatically appear. Day temperature is used during the day, the reduced temperature is used during the day between an OFF interval and the next ON one (if set). Night temperature is used during the night after the last OFF time and first ON time of the next day.

Example:

- Set time: **ON1: 07.00 - OFF1: 22.00**  
**ON2: --- - OFF2: ---**  
**ON3: --- - OFF3: ---**

Between 07.00 and 22.00 Day T. is used; after 22.00 Night T. is used up to the first ON of the next day.

## **Prog. Times**

- >Program
- >Temp. Setting
- >Time Setting
- >Winter Curve

Time program  
Change  
AUTO WEEK. 1

**Submenu 1**

MON. on-off Copy  
07.00 22.00  
--,-- --,--  
--,-- --,--

**Submenu 2**

.... on-off .....  
07.00 22.00  
--,-- --,--  
--,-- --,--

**Submenu 2**

## **CHANGE WEEKLY 1 - 2 PROGRAMME**

**Submenu 2:** Select the Day to be set, and modify the three time bands. To repeat the same time programme for the other days of the week, move cursor to **Copy** and press key “+”. The day will automatically be increased and the three time bands copied.

## **CHANGE DAILY PROGRAMME**

**Submenu 2:** If in submenu 1 the daily programme is selected, the three time bands to be used for every day of the week can be modified if in the “**Programme**” menu the daily programme is selected.

**Submenu 1:** It is used to select the time programme to be changed (Weekly 1 - Weekly 2 or Daily)

## **Winter curve**

>Temp. Setting  
>Time Setting  
>Winter Curve  
>Summer Curve

Heating curve  
Outside T: 20.0c  
Flow Temp:20.0c  
Delay on:00.15hh

**Submenu 1**

Heating curve  
Outside T: 10.0c  
Flow Temp:40.0c  
Delay on:00.30h

**Submenu 2**

Heating curve  
Outside T: 00.0c  
Flow Temp:60.0c  
Delay on:01.15h

**Submenu 3**

Heating curve  
Outside T: -10.0c  
Flow Temp:80.0c  
Delay on:02.15h

**Submenu 4**

**Submenu 2:** Second point of the broken regulation curve where you can modify the external temperature value of the first point, the delivery temperature and the required advance time for that Ext. T. value.

**Submenu 3:** Third point of the broken regulation curve where you can modify the external temperature value of the first point, the delivery temperature and the required advance time for that Ext. T. value.

**Submenu 4:** Fourth point of the broken regulation curve where you can modify the external temperature value of the first point, the delivery temperature and the required advance time for that Ext. T. value.

**Submenu 1:** First point of the broken regulation curve where you can modify the external temperature value of the first point, the delivery temperature and the required advance time for that Ext. T. value.

## **Summer curve**

- >Time Setting
- >Winter curve
- >Summer curve
- >Configuration

Cooling curve  
Outside T.: 35.0c  
Flow T.: 17.0c

**Submenu 1**

Cooling curve  
Outside T.: 30.0c  
Flow T.: 18.0c

**Submenu 2**

Cooling curve  
Outside T.: 27.0c  
Flow T.: 19.0c

**Submenu 3**

Cooling curve  
Outside T.: 23.0c  
Flow T.: 20.0c

**Submenu 4**

**Submenu 1:** First point of the broken regulation curve where you can modify the external temperature value of the first point and the delivery temperature.

**Submenu 2:** Second point of the broken regulation curve where you can modify the delivery temperature

value.

**Submenu 3:** Third point of the broken regulation curve where you can modify the delivery temperature value.

**Submenu 4:** Fourth point of the broken regulation curve where you can modify the external temperature value of the fourth point and the delivery temperature.

## **Configuration**

Controller operating mode is selected in submenu 1:

1. **VALVE**
2. **2-ST. BURN. / 3-ST. BURN. / 4-ST. BURN. / 2BOIL.CASC. / 2BOIL.CASC. / 4BOIL.CASC. / 2-  
2-ST.BOI.**

The other submenus vary according to the operating mode selected.

**N.B.** If the programme selected is **VALVE OPENS** or **VALVE CLOSES**, the boiler operating mode cannot be selected.

- >Winter Curve
- >Summer Curve
- >Configuration
- >Limit Sensor

Output control  
for: VALVE  
Opening time  
Min.: 10.00

or

Output control  
for: 2ST. BURNER  
Differenziale  
Gradi: 05.0c

## **VALVE operating mode**

Output control for: VALVE Opening time Min.: 10.00	<b>Submenu 1</b>
Delay-off time of the pump Min.: 10	<b>Submenu 2</b>
Flow minimum temperature to switch-off Pump: 10.0c	<b>Submenu 3</b>
F.temperature differ.: 02.0c Forced flow temp : 90.0c	<b>Submenu 4</b>
Proportional band Output 0..10V: +/- 15.0c	<b>Submenu 5</b>
Relay No 4 operation mode setting: AUTOMATIC	<b>Submenu 6</b>
Sanitary Water Priority Enabled: NO	<b>Submenu 7</b>

**Submenu 1:** In VALVE operating mode it is necessary to set the mixer valve opening time

**Submenu 2:** To set the delay in pump shut-down. Set 0 minutes to exclude delay

**Submenu 3:** The pump is automatically shut down when in the winter period the delivery temperature calculated by the controller drops below the preset minimum limit value or when in the summer it rises above the preset maximum limit value

**Submenu 4:** The regulation differential (min. 0.5°C max 4.0°C), is the dead zone in which the valve is kept stopped.


**The forced delivery temperature (min 20.0°C max 99.0°C)** is the temperature value regulated during the advance switch-on time. Move the cursor to select the parameter to be modified.

**Submenu 5:** Use keys "+" and "-" to set output 0..10V proportional band

**Submenu 6:** Use keys "+" and "-" to set relay no. 4 operating mode.

**Submenu 7:** Use keys "+" and "-" to set domestic water priority function ON/OFF

## **BOILERS operating mode**



**Submenu 1:** In BOILERS operating mode it is necessary to set the differential used for switching on in sequence boilers / burner stages

**Submenu 2:** To set boiler regulation type: FIXED POINT/SLIDING/CLIMATIC

**Submenu 3:** The boiler temperature calculated is always included between the preset min and max limit values

**Submenu 4:** The set-point temperature is the temperature value used in the fixed point operating mode. The remote temperature represents the max delivery temperature value required by SLAVE modules and is used in the SLIDING operating mode. Boiler rotation expressed in days, is used to select boiler rotation time.

**Submenu 5:** Use keys "+" and "-" to set output 0..10V proportional band

**Submenu 6:** Use keys "+" and "-" to set relay no. 4 operating mode.

**Submenu 7:** Use keys "+" and "-" to set domestic water priority function ON/OFF.

**N.B. When setting the boilers operating mode, make sure the SUMMER period is excluded.**

## Limit Probe

- >Summer Curve
- >Configuration
- >Limit Sensor
- >4..20mA Sensor

Limit sensor  
Temperature  
Set : 50.0c  
Measured: 15.0c

Limit sensor  
value: MAXIMUM

Submenu 1

Submenu 2

**Submenu 1:** Set the desired limit. Set dashes (-----) to exclude this function.

**N.B.** If the limit probe is not connected and a set point value is entered, a limit probe failure will be triggered.

**Submenu 2:** Use keys “+” and “-” to set the desired MINIMUM or MAXIMUM limit.

## Probe 4..20mA

- >Configuration
- >Limit Sensor
- >4..20mA Sensor
- >Aux. Regulation

Configuration  
Limit Sensor  
4..20mA Sensor  
Aux. Regulation

Submenu 1

Configuration  
Limit Sensor  
4..20mA Sensor  
Aux. Regulation

Submenu 2

Configuration  
Limit Sensor  
4..20mA Sensor  
Aux. Regulation


Submenu 3

**Submenu 1:** Set the MINIMUM and MAXIMUM limit and the unit of measurement to be associated to the physical value read by the probe (E.g.: “c” for temperature, “b” for pressure etc..)

**Submenu 2:** Set the values relevant to the two measurement thresholds 4 and 20 mAmpere. **Minimum value: 000 and maximum value: 800**


**Submenu 3:** Set the limit set-point to be used. Set dashes (-----) to exclude this function.

## Auxiliary Reg.



**Submenu 1:** Probe operating mode is selected in submenu: AUXILIARY PROBE/SET CORRECTION/AMBIENT PROBE. When selecting “**Set Correction**” the correction value set on the EC10 by knob is displayed. When selecting “**Ambient Probe**” the temperature value read by the EC10 at that moment is displayed. Selecting “Auxiliary Probe” and “Ambient Probe” will enable a second submenu:

## AUXILIARY PROBE




**Submenu 2:** To select whether to use the **FIXED** or **SLIDING** temperature regulation

**FIXED:** Set temperature will be regulated

**SLIDING:** Set value will be added to the max delivery temperature value required between EV87 and the SLAVE modules connected

## AMBIENT PROBE



**Submenu 2:** It is used to set the K authority in the thermoregulation algorithm. See paragraph “**Auxiliary Regulation**”

## **Remote Management**

>4..20mA Sensor  
>Aux. Regulation  
>Remote Manage  
>Recording

Send message  
Auxiliary  
Treshold  
Overtaking: NO

### **Submenu 1**

Send message  
4..20mAmp  
Treshold  
Overtaking: NO

### **Submenu 2**

Send message  
Flow temp.non  
Reached : NO  
After Hr: 2

### **Submenu 3**

Digital inputs  
And sensors  
Failure status.:  
1 2 3 4 5 6

### **Submenu 4**

Serial  
Connection by  
DATA MODE

### **Submenu 5**

Mobile teleph.  
Number 1  
345645555665454

### **Submenu 6**

EV87 description  
Installation :  
REGOLATORE EV87

### **Submenu 7**

**Submenu 1:** Select “YES” if you want to send a message in remote management when the auxiliary threshold is exceeded

**Submenu 2:** Select “YES” if you want to send a message in remote management when the 4..20mA threshold is exceeded

**Submenu 3:** Select “YES” if you want to send a message in remote management when the desired delivery temperature value is not reached after a certain time (2 to 9 hours), to be set

**Submenu 4:** Describes the status of the probes and of the 2 digital inputs: 1 = External probe failure 2 = Delivery probe failure 3 = Limit probe failure 4 = Auxiliary probe failure 5 = Digital input 1 6 = Digital input 2

**Submenu 5:** To set the modem communication mode: **DATA MODE** or **SMS MODE**

**Submenu 6:** You can enter up to three phone numbers to send SMS messages. If DATA mode is selected the first phone number is used. To enter phone numbers, select mobile phone no. and then enter the relevant digits. Blank identifies the end of the phone number. If the first character entered is blank, the phone number cannot be recognized.

**Submenu 7:** You can customise the name of the master control unit (up to 16 characters) used when sending messages in SMS mode or DATA mode.

Set the **SMS MODE** to communicate with the control unit and to monitor and set the main functions via SMS text messages by mobile phones.

Set the **DATA MODE** to communicate with the control unit via PC using the remote management programme called **FANVISOR**.

In both operating modes, a **triggered alarm or a ceased alarm** will start an alarm sequence to the PC or the mobile phone via SMS. If after 15 minutes no communication is received indicating that the signalling has been received, the control unit will repeat the cycle; the same is done after further 15 minutes. A new cycle will be started at any change in the alarm situation. In SMS MODE at the first alarm call the text message is sent to mobile phone No. 1, at the second call to mobile phones No. 1 and 2 and at the third call to mobile phones No. 1 2 and 3.

## Datalogger

>Aux. Regulation  
>Remote Manage  
>Recording  
>SLAVES Menu

Rec. Number :  
Regime: NIGHT  
All: ----  
00.00 MON.

Submenu 1

Tm: 33.5c Tmc: 65,5c  
Tl: 30.5c Te: 15.5c  
4..20mA: 350c  
Tx: 25.5c

Submenu 2

Rec. Number : 28  
Regime: DAY  
All: - - - 4 - -  
10.15 SUN.

Submenu 55

Tm: 33.5c Tmc: 65,5c  
Tl: 30.5c Te: 15.5c  
4..20mA: 350c  
Tx: 25.5c

Submenu 56

**Submenu 1:** To display data relevant to the last recording made with: recording number, operating mode, alarms, time and day

**Submenu 2:** To display data relevant to the last recording made with: delivery temperature measured, delivery temperature calculated, temperature measured by the limit probe, external temperature, physical value read by probe 4..20mA and temperature measured by the auxiliary probe.

**Submenu 55:** To display data relevant to the oldest recording

**Submenu 56:** To display data relevant to the oldest recording

Recording usually takes place every 2 hours. Each time there is a change in operating modes, recording is repeated for eight times every 15 minutes to verify for example how delivery temperature and ambient temperature change after a change in operating modes.

## Memorise SLAVE

>Remote Manage  
>Recording  
>SLAVES Menu  
.....

Press '+' to  
search SLAVE  
Press '>' to  
Visualize SLAVE

**Submenu 1**

MENU SLAVE -->  
EV91A 10  
EV92 30

**Submenu 2**

**Submenu 1-2:** Press key "+" to start searching all the connected SLAVES. This operation shall certainly be carried out at first installation, and also each time a new SLAVE module is added. If SLAVE modules are memorised pressing key ">" will open submenu 2 "SLAVE MENU", otherwise you go back to the main menu.

Submenu 2 lists the memorised slave modules use keys ▲ and ▼ to scroll. The SLAVE module to be handled will be highlighted by the blinking cursor.


Press key ► to open the menu relevant to the slave selected. For details on the slave menu refer to the SLAVE instruction sheet.

N.B. Search of connected SLAVE control units is to be performed just once. The SLAVE control unit, identified by an address, is memorised by the EV87 MASTER. This information will be kept also if power supply is lacking.

## **REMOTE CONTROL AND REMOTE MANAGEMENT**


The EV87 controller and the connected SLAVES can be remotely managed via SMS mode or DATA MODE communication, to be selected in the “**Remote Management**” menu.

### **Connection to the DB9 connector**



Follow this diagram to connect the serial cable to the modem

### **SMS mode**



By connecting the EV87 controller through a serial cable to a GSM modem and setting the SMS mode, the significant parameters of the control unit can be set and read using the SMS commands listed in the following pages. SLAVE control units connected to the MASTER can also be queried via SMS commands. These commands are listed in the instruction sheets relevant to each device.

To properly communicate with the desired device (MASTER or SLAVE), every command must be preceded by two digits identifying the device's address. More particularly, to address commands to the EV87 controller, you must first enter “00”.

The GSM modem works with any SIM card. Before using one with the Modem, however, we recommend that you test it in a mobile phone to see if it's working. Particularly:

- Check that no PIN code has been set. If so, exclude it
- Check the remaining credit if the SIM card is of the rechargeable credit type
- Send an SMS message and check if it arrives

### **Remote management SMS commands**

These commands may be used through a mobile phone by sending an SMS message containing the command message to the SIM number of the modem connected to the EV87 controller that will answer with a reply message to the phone number that has sent the SMS. To facilitate the reply message reading, the information is enclosed in a “<” and “>” sign. Every reply message is preceded by a description of the EV87 control unit.

- **00ORA=?** Requests information about the state of the EV87 controller

Reply:

```
<Desc.EV87><Giorno><ora.min><TE=...,c><TM=...,.c><TL=...,c>
<T x = . . . c > < 4 . . 2 0 m A = . . . c > < T .
Remot.=...,c<Programma><Regime>
```

- **00TA=?** Requests the ambient temperatures set (Day-Night-Reduced-Antifreeze)

Reply:

```
<Desc.EV87><TAG=...,c><TAR=...,c><TAN=...,c><TAA=...,c>
```

- **00TM=?** Requests the four delivery temperature values set on the broken regulation curve

Reply:

```
<Desc.EV87><TME1=...,c><TME2=...,c><TME3=...,c><TME4=...,c>
```

- **00PROGG=?** Requests the programme schedule for the day

Reply:

```
<Desc.EV87>
<PROGG      ON-OFF><06,00      08,45><12,00
16,30><18,00 22,30>
```

- **00PER-I=?** Requests the heating period

Reply:

```
<Desc.EV87>
<PER-I=01/01 31/12>Start 1st January   End 31st
December
```

- **00PER-E=?** Requests the air-conditioning period

Reply:

```
<Desc.EV87>
<PER-E=01/05 30/09>Start 1st May   End 30th Sep-
tember
```

- **00PROG(1-7)S(1-2)=?** Requests the programme

schedule for the weekly programme 1 or 2 for a day.

**Example:** PROG3S2=? Request the programme schedule for the day Wednesday of the Weekly programme 2

Reply:

```
<Desc.EV87>
<PROG3S2    ON-OFF><06,00      08,45><12,00
16,30><18,00 22,30>
```

- 00ORA=12.15 Sets the current time

Reply:

```
<Desc.EV87><Giorno><ora.min><TE=,,,c><TM=,
.,c><TL=,,,c>
< T x = . . . c > < 4 . . 2 0 m A = . . . c > < T .
Remot.=,,,c><Programma><Regime>
```

- 00TAG=15.5 Sets the day temperature

- 00TAN=15.5 Sets the night temperature

- 00TAR=15.5 Sets the reduced temperature

- 00TAA=15.5 Sets the antifreeze temperature

Reply for all the above 4 commands:

```
<Desc.EV87><TAG=,,,c><TAR=,,,c><TAN=,,,c><
TAA=,,,c>
```

- 0000TME1=10.0 Sets the delivery temperature point one on the broken regulation curve

- 00TME2=40.0 Sets the delivery temperature point two on the broken regulation curve

- 00TME3=60.0 Sets the delivery temperature point

three on the broken regulation curve

- 00TME4=80.0 Sets the delivery temperature point four on the broken regulation curve

Reply:

```
<Desc.EV87><TME1=,,,c><TME2=,,,c><TME3=.,
.c><TME4=,,,c>
```

- 00PROGG=10.00 12.00 --. --. -- 17.00 22.00 Sets the programme schedule for the day

<Desc.EV87>

```
<PROGG    ON-OFF><06,00      08,45><12,00
16,30><18,00 22,30>
```

- 00PROG(1-7)S(1-2)=10.00 12.00 --. --. -- 17.00

22.00 Sets the programme schedule for the weekly programmes. **Example:** 00PROG2S1=10.00 12.00 --. --. -- 17.00 22.00 Sets the programme schedule for the Weekly programme 1 of the day Tuesday

Reply:

```
<Desc.EV87>
<PROG2S1  ON-OFF><10,00  12,00>< --. --. --
><17,00 22,00>
```

- 00PAUT1 Sets the Automatic Weekly 1 Programme

- 00PAUT2 Sets the Automatic Weekly 2 Programme

- 00PAUTG Sets the Automatic Daily Programme

- 00PNOT Sets the Night Programme

- 00PGIO Sets the Day Programme

- 00PANT Sets the Antifreeze Programme

Reply:

<Desc.EV87><Giorno><ora.min><TE=..,c><TM=..,c><TL=..,c>  
<T x = . . . c > < 4 . . 2 0 m A = . . . c > < T .  
Remot.=..,c<Programma><Regime>

- **PER-I= 02/01 10/10** Sets the heating period from the 2nd January to the 10th October. Reply as indicated above.
- **PER-E= 01/05 30/07** Sets the air-conditioning period from the 1st May to the 30th July. Reply as indicated above.

**N.B. To exclude the air-conditioning period send command:**  
**PER-E= --**

• **RESETTA**

• **SI**

Both messages communicate to the control unit that alarms have been received, the alarm sending cycle can therefore be stopped

Reply:

<Desc.EV87><ALLARMI CANCELLATI>

Sending ALARMS via SMS messages

The alarmed control unit sends the following message:

<Desc.EV87><ALL.SONDE 1 2 3 4><ALL.INPUT 1

>><SOGLIA AUX.>

<SOGLIA 4..20mA><TEMP.MANDATA NON RAGGIUNTA>

The message is composed according to the failure present. The above example describes the presence of all possible failures.

Examples:

1. for failure involving just the external probe the message will be:

<Desc.EV87><ALL.SONDE 1 - - ->

2. for failure involving just the digital input 2 the message will be:

<Desc.EV87><ALL.INPUT - 2>

3. for failure involving the external probe and the digital input 1 the message will be:

<Desc.EV87><ALL.SONDE 1 - - -><ALL.INPUT 1 ->

4. for failure involving the external probe, the limit probe and the digital input 1 the message will be:

<Desc.EV87><ALL.SONDE 1 - 3 -><ALL.INPUT 1 ->

Messages "AUX. THRESHOLD exceeded", "4..20mA THRESHOLD exceeded" and "DELIVERY TEMP. NOT REACHED" can only be sent if the relevant function has been enabled in the "**Remote Management**" menu.

When passing from an alarm situation to a ceased

alarm situation, the control unit will send the following message:


<Desc.EV87><NESSUN ALLARME>

### **DATA mode**

By connecting the EV87 controller through a serial cable to a modem and setting the DATA mode, the significant parameters of the control unit can be set and read using a **PC** on which has been installed the operating software called FANVISOR.

The FANVISOR software enables to read and to set the significant parameters of the EV87 controller and the connected SLAVE units. Moreover, it receives automatically all existing failures and it stores them in a file of prompt consultation.

### **Dimensions**



## **Technical Data**

- Power supply: 230 Vac +/- 10%
- Consumption: 5VA
- Protection: IP40
- Contact rating: 5(3) A - 230 Vac
- Ambient temperature: 0...45°C
- Software: Class A
- RS232 serial port for modem connection
- 2 digital inputs
- One 4..20mA input
- One 0..10V output (max load 3mA)
- Data stored for 5 years
- DIN container - 6 modules
- 2 weekly programming with 3 time bands per day
- One daily programming with 3 time bands
- Clock charge: 5 years
- External probe detection range: -30..+40°C
- Delivery/limit/auxiliary probe detection range: 0..+99°C
- ErP classification: ErP Class VI; 4% (EU Reg. 811/2013 - 813/2013)

## **Contents**

<b>Employment</b> .....	1
<b>Description</b> .....	1
Mixer valve .....	2
Boilers .....	2
Climatic regulation .....	2
Fixed point regulation .....	2
Sliding point regulation .....	2
<b>Front panel with configuration keys and indications</b> .....	3
<b>Broken regulation curves</b> .....	3
Preset values for the WINTER broken regulation curve	4
Summer broken regulation curve .....	4
Preset values for SUMMER broken regulation curve .....	5
<b>Switch-on time optimization (winter only)</b> .....	5
<b>Temperature probes</b> .....	6
Technical data .....	6
Installing the delivery-limit-auxiliary probe EC15-EC16	7
Installing the ambient probe EC10 .....	7
<b>Operation periods</b> .....	7
Heating period .....	7
Air-conditioning period .....	7
<b>Operation programmes</b> .....	8
<b>Limit probe</b> .....	9
<b>Auxiliary regulation</b> .....	9
Auxiliary probe .....	9
Ambient probe .....	9
Set correction .....	10
<b>Probe 4..20mA</b> .....	10
<b>Output 0..10V</b> .....	10
Relay .....	11
Mixer valve operation .....	11
Burner/boiler operation .....	11
<b>Circulation pump control</b> .....	12

<b>Domestic water priority .....</b>	<b>12</b>
<b>FANBUS .....</b>	<b>12</b>
Control unit address .....	12
<b>SYSTEM EXAMPLES .....</b>	<b>13</b>
Heating of 1 area with one 1-stage boiler .....	13
Heating of 1 area with domestic water storage tank ....	14
Heating of 2 areas with one 1-stage boiler and 1 domestic water storage tank .....	14
Heating of 3 areas with one 1-stage boiler (1 EV87 + 2EV91A) .....	14
Heating of 2 areas with two 2-stage boilers in cascade (1 EV87 2 EV91A) .....	15
Heating of 2 areas with four 1-stage boilers in cascade (1 EV87 2 EV91A) .....	15
Heating/Air-conditioning for panel systems .....	15
<b>Wiring diagrams .....</b>	<b>16</b>
Terminal board wiring diagram .....	16
Wiring diagram for control of mixer valves with servo control supplied at 230VAC .....	16
Wiring diagram for control of mixer valves with servo control supplied with voltages other than 230VAC .....	17
Wiring diagram for ON-OFF control of four 1-stage boilers .....	17
Wiring diagram for ON-OFF control of two 2-stage boilers .....	18
Wiring diagram for ON-OFF control of a 4-stage burner boiler .....	18
<b>Operation with 2/4-stage boilers or boilers in cascade ..</b>	<b>19</b>
<b>Alarms and Failures .....</b>	<b>19</b>
<b>Settings and Adjustments .....</b>	<b>20</b>
Factory settings .....	20
Adjustments .....	20
Password .....	21

<b>CONTROL UNIT CONFIGURATION MENU .....</b>	<b>21</b>
Main menu .....	21
Information .....	22
Set Current Time .....	23
Enter Password .....	23
Choose LANGUAGE .....	24
Heating period .....	24
Cooling period .....	25
Programme .....	25
Set Temperature .....	26
Prog. Times .....	27
Winter curve .....	28
Summer curve .....	29
Configuration .....	29
VALVE operating mode .....	30
BOILERS operating mode .....	31
Limit Probe .....	32
Probe 4..20mA .....	32
Auxiliary Reg. .....	33
AUXILIARY PROBE .....	33
AMBIENT PROBE .....	33
Remote Management .....	34
Datalogger .....	35
Memorise SLAVE .....	36
<b>REMOTE CONTROL AND REMOTE MANAGEMENT .....</b>	<b>37</b>
Connection to the DB9 connector .....	37
SMS mode .....	37
Remote management SMS commands .....	38
DATA mode .....	41
<b>Dimensions .....</b>	<b>41</b>
<b>Technical Data .....</b>	<b>42</b>



#### DISPOSAL OF PRODUCTS

The crossed out wheeled dust bin symbol indicates that products must be collected and disposed of separately from household waste. Integrated batteries and accumulators can be disposed of with the product. They will be separated at the recycling centres. The black bar indicates that the product was placed on the market after August 13, 2005. By participating in separate collection of products and batteries, you will help to assure the proper disposal of products and batteries and thus help to prevent potential negative consequences for the environment and human health. For more detailed information about the collection and recycling programmes available in your country, please contact your local city office or the shop where you purchased the product.